



Faceshield Mounting Hardware Kit for Advent Helmet - ADFB

Kit includes:

- 2 brass nuts
- 2 accessory blades
(right and left)
- 2 faceshield washers
- 2 hitch pins
- 2 tension knobs



Americas:

E.D. Bullard Company
1898 Safety Way
Cynthiana, KY 41031-9303
Toll free: 877-BULLARD (285-5273)
Tel: 859-234-6616
Fax: 859-234-8987
www.bullard.com

Europe:

Bullard GmbH
Lilienthalstrasse 12
53424 Remagen
Germany
Tel: +49-2642 999980
Fax : +49-2642 9999829
www.bullardextrem.com

Asia-Pacific:

Bullard Asia Pacific Pte. Ltd.
LHK Building
701, Sims Drive, #04-03
Singapore 387383
Tel: +65-6745-0556
Fax: +65-6745-5176
www.bullard.com

Assembly Instructions

1. Assemble brass nut, accessory blade (right), faceshield washer, hitch pin, and tension knob as shown in drawing.

2. Repeat step 1 for left side.

3. Insert accessory blades in accessory slots on sides of helmet.

4. Release tension knobs to raise or lower faceshield. Tighten knobs to secure faceshield in position.

